

www.snail-audio.com

User's Manual



SNAIL POWER

Enjoy Snail Sound, Touch Your Soul!

MODEL:U4max 5.1 SYSTEM

2024-10 C版

From Italy Snail Power

Warranty Policy and Customer Service Information

Thank you for purchasing **SNAIL POWER** products. If there is a product quality problem within 12 months from the date of purchase, you can enjoy the company's warranty service.

NOTES:

- 1. A valid proof of purchase must be issued by the seller when purchasing.
- 2. The warranty card and proof of purchase should be properly kept by the user and cannot be lost, no repeat issuing if lost.
- 3. if the product appear for the causes of failure, the user can use the warranty card and purchase certificate

Non-warranty Situation:

During the user's operation, those that meet one of the following conditions are not covered by the warranty.






- 1. The warranty period is exceeded.
- 2. Damage caused by failure to use in accordance with the requirements in the user's instruction manual.
- 3. Damage caused by human factors.
- 4. Failures caused by unauthorized disassembling, repair, and modification of products.
- 5. Damage caused by force majeure factors (such as floods, earthquakes, lightning, etc.).
- 6. No warranty card, invoice or warranty card does not match the invoice information.
- 7. The product wears out naturally.
- 8. Failure and damage caused by other non-product quality problems.

U4max5. 1 SYSTEM

1: Technical parameters

Drive Units:	1x4.5"LF Driver,1x1"HF Driver
Frequency Response:	50Hz-20KHz (On wall -10dB)
Power lutup:	80 ~ 300W
Sensitivity:	90dB/W/m
Avg. Max Output @1m:	110dB
Rated Impedance:	6Ω
Inputs:	Bindingpost
Dimensions:	290x135x97mm
Net weight:	2.6Kg (Single)

2: Accessories

U4max U4Cmax	A Iron plate(5PCS,Mounted behind the housing) 	C Screw(5PCS,Mounted behind the housing) 	E Wall plug(15PCS,Put it in the accessory box) 	F Foot pad(10PCS,Put it in the accessory box) 	G Hexagon bar wrench(1PC,Placed in the U4Cmax Accessory box) 
	B Wall bracket(5PCS,Put it in the accessory box) 	D Screw(15PCS,Put it in the accessory box) 			

U4max5. 1 SYSTEM

3:The layout of speaker installation

U4max: ❶ ❷ ❸ ❹

U4Cmax: ❺

S10D: ❻

Explanation for speaker installing:


A:The front speaker is mounted on the two sides of the screen about 20cm,and the top of speaker and screen should be aligned.

B:Center speaker (the positionis) depending on the site layout);

1:Mounting the speaker under the screen about 10cm;


2:Mounting the speaker at the top of screen about 10cm;

C:The surround speaker is mounted above the ears of listener about 40 cm,with a standard distance of 20cm on both sides of the sofa.



U4max5. 1 SYSTEM

4:The connection diagram of speaker and amplifier




U4max/U4Cmax


5:The way of U4max and U4Cmax speaker installation

(NOTE:U4max and U4Cmax are fixed in much the same way; U4Cmax is vertical and U4Cmax is horizontal)

A:The standard way of installation(wall mounting)




B:Installtion of desktop bracket(The desktop bracket need to be order separately)




U4max/U4Cmax

C:The way of floor bracket installation(The floor bracket need to be order separately)




U4max/U4Cmax

D:The way of wall bracket installation(The wall bracket need to be order separately)



U4max/U4Cmax

6:U4max&U4Cmax ENCLOSURE DIMENSIONS(Only the iron mesh is different)



U4max UNIT:mm

U4Cmax UNIT:mm

S10D


1: Product Features

- High level frosted surface (fingerprint proof) + tempered glass;
- Active super Subwoofer, Dynamic, natural, powerful and surrounded with ultra-bass vibration.
- Active integration with built-in amplifier.
- Active subwoofer.
- All materials meet ROHS requirement.

2: Technical parameters

Drive Units:	10" Driver+10"passive bass vibration films;
Frequency Response:	25Hz-200Hz;
Amplifier Power Output:	1000 watts RMS short-term;
Sensitivity:	86±3dB/W/m(100Hz);
Crossover Range:	80~160Hz;
Inputs:	RCA Line(2VP-P);
Input Impedance:	6Ω;
Signal-to-noise ratio(S/N):	>86dB(100Hz A WEIGHTED);
Avg. Max Output @1m:	119dB;
Features :	0.5W low standby power consumption; Thermal shutdown; Short circuit and overload protection;Permanent high frequency protection; Proprietary DSP module;
Voltage:	AC 220V-240V 50Hz;
Dimensions:	295(L)X295(W)X405(H)mm;
Net weight :	20Kg;
Gross weight:	22Kg;

3: Product Accessories



S10D


4: Front panel function instruction

Power Indicator LED

ON	BLUE	Detected audio input, triggered the power, in normal working mode.
STANDBY	RED	waiting for the audio signal to triggered Power, in standby mode.
OFF	Non	No AC 220V power input.

Power Auto/Always on


This subwoofer can be safely left with the main power switch on continuously. The subwoofer will turn itself on automatically when an audio signal is present. If no signal is present for approximately 15 mins, the unit will switch to standby mode (indicated by red power LED color).While in standby mode, your subwoofer will draw very minimal power.



Power indicator light

S10D

5: Back panel function Introduction



1: EQ MODE SWITCH

MOVIE: According to the setting of the living room, it is recommended to use in more than 20 square meters or Unconfined space.

MUSIC: Suitable for pure music, hi-fi music, listening to music in a variety of environments.

KTV: Audio effects for karaoke venues designed to provide a high quality music and singing experience.

TV: For watching TV, news programs.

2: USB SOCKET

DSP Debugging Service or power supply 5V/500mA.

3: RS232 INPUT INTERFACE

The external device sends instructions to the subwoofer, and the subwoofer switches the corresponding EQ mode.

4: INPUT


RCA Input(2VP-P), DVD, CD, AV power amplifier SUB signal or audio output of other devices can be directly connected to the subwoofer INPUT.

5: Power input socket

AC220V-240V-50Hz; Built-in fuse tube 2 PCS (T5L250V), size $\phi 5 \times 20$ mm

S10D


6: Finished dimension drawing



S10D

7: A/V Processor Connections

S10D super subwoofer is designed to optimized with mainstream AV amplifier. Use attached RCA cable to connect from AV amplifier subwoofer Output pole with S10D Subwoofer Input. Refer drawing to connect the cable.




8: Setup Home Theater System

Home Theater Speaker: The two front speakers can be placed on two side of TV screen located at ¼ section of the front wall. (as shown in the picture).The speaker is tilted slightly towards the listener. It is recommended to place the rear-surround speaker in a higher position behind the listener's head. If the back wall far from the listener's seat, could consider using floor stand. If the position of center speaker is too high or too low, tilt it slightly toward the listener's ear. The center speaker should be further away from the direct line of surround speaker's front side. Using AV amplifier's automatic testing function for calibration and adjustment.

Super Subwoofer: human ear cannot distinguish the direction of the bass, the Super Sub could be placed freely. The distance of the Sub from the wall will affect the bass performance. Putting it in the corner might enhance the bass but may reduce the clarity. If you use two super Sub same time, it will enhance the performance of your home theater system.

9: Multi-channel Placement

DolbyLabs, DTS, and THX provide 5.1 and 7.1 layouts. The exact structure of these systems depends on the performance of your processor, we will also provide some experimental results for your reference. With 5.1 and 7.1 system, the position of listener should notbe too close to the rear wall.To fully perform the benefitsof these systems, it is important to make sure that signals from all speakers reach DolbyLabs' multi-channel home theater system layout simultaneously.



S10D

IMPORTANT SAFETY INFORMATION

CAUTION!
RISK OF ELECTRIC SHOCK
DO NOT OPEN

TO REDUCE THE RISK OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK)
NO USER-REMOVEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED PERSONNEL

AVERTISSEMENT: RISQUE DE CHOC ELECTRIQUE- NE PAS OUVRIR

This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with cloth.
- Do not block any ventilation openings.
- Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarised or grounding plug. A polarised plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into you outlet, consult an electrician for replacement of the obsolete outlet. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. Only use attachments/accessories specified by the manufacturer.

Unplug the apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been exposed to rain or moisture, does not operate normally, or has been dropped.

CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

No naked flame sources, such as lighted candles, should be placed on the apparatus.

WARNING: The mains plug/appliance coupler is used as disconnect device shall remain readily operable.

U4max 5.1 SYSTEM



Correct disposal of this products. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or humanhealth from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



This equipment is a class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

ROHS hazardous substances management

Hazardous substance	Drive	Crossover	Wire	Iron grille	Enclosure	Accessories
Pb	○	○	○	○	○	○
Hg	○	○	○	○	○	○
Cd	○	○	○	○	○	○
Cr,Vi	○	○	○	○	○	○
PBB	○	○	○	○	○	○
PBDE	○	○	○	○	○	○

Indicating that the content of the hazardous substances in all homogeneous materials of the components are under the limit requirements in GB/T26572011.

U4max 5.1 SYSTEM

SERVICE CARD

I hope our sincerely services can accompany you life.
Your praise is our greatest power for making progress!



Genuine guarantee



Invoice



7days return

After-sale service card

✓ 7days return When the goods package is not open and accessories are not missing within the 7 days, It could be enjoy the "7 days return" service. Excluding the products of "CAUTIONS" agreements that don't enjoy the return service.	✓ 15days replacement 1.Commodity quality problem. 2.Logistics damage.	✓ 12months warranty 1.Within the warranty period.
CAUTIONS ① The following conditions don't enjoy the 7 days return service: 1.Over 7 days return service warranty period; 2.The package of goods has been opened; 3.The commodity accessories are missing; 4.The quality of goods caused by man-made damage; ② The following conditions don't enjoy 15 days replacement service: 1.Product quality problems caused by man-made damage; 2.Vexatious request for replacement; ③ The following conditions don't enjoy 12 months warranty: 1.The warranty period has expired; 2.The quality of goods caused by man-made damage.		

Warm tips:

- 1.We don't accept the freight collect and postage when you return the goods!
2.Please ensure that the product is intact when you return. If you are not satisfied with the gift, please return the gift with products together.

First of all, sincerely apologize to you for whatever reason to return, we are extremely sorry!

If you haves any questions,please communicate with us promptly, we will solve it for you as soon as possible!

Web:www.snail-audio.com

After-sale service registration from

Customer information

Name: _____ Telephone: _____
E-mail: _____ Postal code: _____
Address: _____

Product information

Model: _____ Product barcode: _____
Finishing:_____ Serial number: _____
Order number: _____ Delivery number: _____

Dealer information

Dealer Name: _____ Telephone: _____
Address: _____

The reason for return: _____
Problem description: _____
Others: _____

Return requirements:

☐ Return ☐ Replacement



1: 技术参数

喇叭单元:	1x4.5" LF Driver, 1x1" HF Driver
频响范围:	50Hz-20KHz (On wall -10dB)
输入功率:	80 ~ 300W
灵 敏 度:	90dB/W/m
最大声压@1m:	110dB
额定阻抗:	6Ω
输入接口:	Bindingpost
产品尺寸:	290x135x97mm
产品净重:	2.6Kg (Single)

2: 附件

U4max U4Cmax	A 铁板(5PCS, 安装在外壳后面) 	C 螺丝(5PCS, 安装在外壳后面) 	E 墙塞(15PCS, 放在附件盒中) 	F 脚垫(10PCS, 放在附件盒中) 	G 内六角扳手(1个, 放在U4Cmax附件盒中)
	B 墙面支架(5PCS, 放在附件盒中) 	D 螺丝(15PCS, 放在附件盒中) 			

U4max5.1 SYSTEM

三: 音箱安装位置分布图


U4max: ① ② ③ ④
U4Cmax: ⑤
S10D: ⑥

音箱安装位置说明:

A: 前置音箱安装与屏幕顶部
齐平,距离幕布两侧各20CM:


B: 中置音箱(依现场布局面而定)
1:在幕布正中下方,距离底部10CM;
2:在幕布正中上方,距离顶部10CM;

C: 后置音箱安装在聆听者背后耳朵上
方高度最少40CM,以沙发两侧为标准
距离为20CM;



U4max5.1 SYSTEM


四: 音箱与功放连接示意图




U4max/U4Cmax

五: U4max和U4Cmax扬声器的安装方式
(注:U4max和U4Cmax的固定方法大致相同; U4Cmax是垂直的, U4Cmax是水平的)

A:标准安装方式(壁挂式)




B:桌面支架安装(桌面支架需另行订购)




U4max/U4Cmax

C: 落地支架安装方式(落地支架需另行订购)




U4max/U4Cmax

D:墙壁支架安装方式(墙壁支架需单独订购)




U4max/U4Cmax

六:U4max&U4Cmax外观尺寸(只有铁网不同)



U4max UNIT:mm



U4Cmax UNIT:mm

S10D



1：产品特性

- 表面顶级磨砂面(防指纹)+钢化玻璃;
- 主动辐射式超低音箱,丰满自然、宽松磅礴、包围感强烈的超低频振撼感;
- 有源一体化,内置放大器;
- 有源低音炮;
- 所用的材料均符合ROHS标准;

2：技术参数


喇叭单元: 10" Driver+10"超低音被动单元;
频响范围: 25Hz-200Hz;
功放输出功率: 1000 watts RMS short-term;
灵 敏 度: 86±3dB/W/m(100Hz);
建议分频点: 80~160Hz;
输入接口: RCA线路输入(2VP-P);
标称阻抗: 6Ω;
信噪比(S/N): >86dB(100Hz A WEIGHTED);
最大声压(@1m): 119dB;
功能特性: 0.5W低待机功耗;过热关机保护;短路和过载保护;
永久高频保护;专有的DSP模块;
使用电源: AC 220V-240V 50Hz;
成品尺寸: 295(L)X295(W)X405(H)mm
产品净重: 20Kg;
产品毛重: 22Kg;

3：标配附件



S10D

4：前面板功能说明



电源指示灯

1:电源指示灯


开机	蓝色	检测到音频信号输入，触发开机，处于正常工作状态
待机	红色	等待音频信号触发开机，处于待机状态
关闭	无	无AC220V电源输入

2:电源(自动/始终开启)

本超低音音箱可以持续安全工作，如果有音频信号输入时，超低音音箱会自动开启。如果15分钟左右都没有信号输入，超低音音箱会自动切换到待机模式（LED显红灯）。在待机模式下，您的超低音音箱会消耗最小的功率。

S10D


5: 后面板功能说明



- 1: EQ模式切换
MOVIE: 按客厅使用场景设置, 建议在20平方以上或非密闭空间使用。
MUSIC: 适合纯音乐,高保真音乐, 在各种环境中倾听音乐。
KTV: 用于卡拉OK场所的音频效果, 旨在提供高质量的音乐和歌唱体验。
TV: 用于观看电视,新闻节目。
- 2: USB插座
DSP调试服务或电源供应5V/500mA
- 3: RS232输入接口
外部设备发送指令给低音炮,低音炮进行相对应EQ模式切换。
- 4: INPUT
RCA线路输入(2VP-P), DVD, CD, AV功放SUB信号或其它设备音源输出, 可直接连接本产品输入端INPUT接口。
- 5: 电源输入插座, AC220V-240V-50Hz;
内置保险丝管2PCS,规格T5L250V, 尺寸φ5x20mm。

S10D


6: 外观尺寸图



S10D


7：A/V处理器连接

S10D超重低音音箱是与主流AV功放最优搭配而设计。
AV功放的SUBWOOFER OUTPUT的输出接口与S10D低音炮的SUBWOOFER INPUT接口连接即可(机器内配置单声道信号屏蔽的RCA导线)，按右图将导线与音箱的低音效果信号输入端连接。



8：家庭影院系统的设置

家庭影院音箱：前置主音箱可放在电视屏幕的两侧，音箱的位置约在前方的墙面1/4处（如图所示）。音箱稍微向听者位置倾斜摆放。建议将后环绕音箱放在听者头部后方的一个较高位置。如果后墙和侧墙离听者座位较远，可考虑将音箱架在落地支架上。如果中置音箱过高或过低，将其稍微向听者耳朵处倾斜。中置音箱离环绕音箱的前面板所在直线应尽可能远。调试应该使用AV功放的自动测试的功能进行校正和调整。
超重低音音箱：由于人耳无法分辨出较低沉的低音发出的方向，所以超重低音音箱可以自由摆放位置。音箱离墙壁的距离会影响低音效果。将其放在墙角会增强低音但可能会使清晰度减弱。如果同时使用两个超重低音音箱，会增强家庭影院系统的演示效果。



9：多通道系统的摆放

DolbyLabs，DTS和THX提供了5.1和7.1布局。这些系统的精确结构取决于您的处理器的性能，但我们会提供一些试验结果，以供您参考。
在5.1和7.1布局中，听者位置离后方墙壁不要太近。
为充分实现这些系统的优点，应尽量使所有音箱发出的信号同时到达听者。
DolbyLabs的多声道家庭影院系统摆放方案。

U4max 5.1 SYSTEM

重要的安全提示

警告！

小心触电
请勿打开

为减少触电的风险，请勿私自拆开面板，机身内部无任何用户可自行更换的零部件，如果出现异常，请咨询专业人员。

此标志表示包装盒内附带有重要的操作指引和维修说明书。

此标志表示机身存在的高电压有可能引起触电风险。

请阅读此说明书。

请保留此说明书。

请留意所有的警告标示。

请遵循所有的操作说明。

请勿将本产品靠近水源。

仅能使用干布清洁机身。

请勿阻塞各通风口。

请按生产商的说明书进行安装操作。

请勿靠近任何热源进行安装，比如散热器、热调温器、火炉及其他散热设备（包括功放）。

请勿损坏带极性插头或接地型插头的安全性能。带极性插头一般有两个宽度不一的插片而接地型插头除这两个插片外还带一个接地插片，其中稍宽点的插片及接地插片是为了保障用户安全而提供。如果产品上的插头与用户插座不匹配，请咨询相关专业人士更换合适的插座。

保护好电源线，避免被踩踏或碾压，尤其是插头、便捷式插座及设备输出端口处。

仅使用厂商所指定的附件或零件。

雷电天气或长时间不使用该产品时，请将电源插头拔出。
所有的维修服务，请咨询专业的维修人员。当产品出现以下任何形式的损坏时可以要求维修，比如电源线或插头损坏、液体溅入或设备内掉入异物、产品淋雨受潮、非正常操作或产品被摔落等情况。

警告：为减少火灾及电击的危险，请勿将产品淋雨受潮。产品不能够被溅湿，请勿将任何装有液体的容器如花瓶放在本产品上方。

请勿将任何明火放置于产品上面，如蜡烛。

警告：电源插头被作为本产品的断电装置，请保持插头能进行方便操作。

U4max 5.1 SYSTEM



该标志表明本产品报废后应进行合理的处置且不能与生活垃圾一同处理。为了防止对环境及人体健康可能造成的危害，可对该产品进行合理回收以促进材料的可持续使用。如果要退回该产品，应通过正规的回收渠道进行回收或联系此产品的经销商，他们可对其进行无公害的安全回收。



该产品已符合II类设备的安全要求，电源连接时不需要接地。

ROHS有害物质管理

有毒&有害物质	喇叭	分音器	电线	铁网	箱体	附件
铅 (Pb)	○	○	○	○	○	○
汞 (Hg)	○	○	○	○	○	○
镉 (Cd)	○	○	○	○	○	○
六价铬 (Cr,Vi)	○	○	○	○	○	○
多溴联苯 (PBB)	○	○	○	○	○	○
多溴联苯醚 (PBDE)	○	○	○	○	○	○

表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T26572011规定的限量要求以下。

U4max 5.1 SYSTEM

SERVICE CARD

售后服务保障卡

希望我们的真诚服务 能够陪伴你一生
您的好评是我们进步的最大动力！

正 正品保障

提供发票

七 七天包退

U4max 5.1 SYSTEM

售后服务

✓ 7天包退

7日之内, 商品包装未拆, 配件完整无缺, 注意事项约定不做退货处理的产品除外! 可享7天包退服务!

因物流造成商品损坏!
商品本身质量问题!

✓ 15天包换

1. 商品质量问题!
2. 物流造成商品损坏!

✓ 12个月保修

1. 确定在保修时效之内!

!

注意事项

① 以下情况, 不享七天包退服务:

1. 超过七天包退时效! 2. 商品包装已拆封!
3. 商品配件缺失! 4. 人为因素造成商品损坏!

② 以下情况, 不享受15天包换服务:

1. 人为因素造成产品质量问题!
2. 本人主观因素, 无理取闹要求换货者!

③ 以下情况, 不享受12个月保修服务:

1. 保修服务时效过期!
2. 人为损坏造成商品质量问题!

温馨提示:

1. 退换货快递不接受到付件及平邮!

2. 办理退货, 请确保产品完好, 如不满足满赠要求, 请将赠品一并退回

首先真诚的向您道歉, 无论任何原因让您需要退换货, 我们都致以万分歉意!

如果您有任何问题, 请及时与我们沟通, 我们都尽快为您解答!

官网: www.snail-audio.com

售后服务登记表

用户信息

姓 名: _____ 联系电话: _____

电子邮件: _____ 邮政编码: _____

家庭地址: _____

产品信息

機種型号: _____ 产品条码: _____

表面处理: _____ 序 列 号: _____

订购单号: _____ 发货单号: _____

经销商信息

销售商名称: _____ 联系电话: _____

地 址: _____

退换原因: _____

问题说明: _____

其他说明: _____

退换要求: ☐ 退货 ☐ 换货

