




封面120克铜版纸，过膜，
内页80克铜版纸

↑ 中间对折装钉

Warranty Policy and Customer Service Information

Thank you for purchasing SNAIL POWER products. If a product quality issue occurs within 12 months from the date of purchase, you are entitled to warranty service.

NOTES:

- 1. A valid proof of purchase must be issued by the seller when purchasing.
- 2. The warranty card and proof of purchase should be properly kept by the user and cannot be lost, Replacement copies will not be issued if lost.
- 3. If this product develops a malfunction due to non-user-induced causes, the user may bring it to the customer service center for repair during the warranty period by presenting the warranty card and proof of purchase.

Non-warranty Conditions:

During the user's operation, those that meet one of the following conditions are not covered by the warranty.

- 1.The warranty period has expired.
- 2. Damage caused by failure to use in accordance with the requirements in the user's instruction manual
- 3. Damage caused by misuse, improper handling, or unauthorized modification.
- 4. Failures caused by unauthorized disassembling, repair, and modification of products.
- 5. Damage caused by force majeure factors (such as floods, earthquakes, lightning, etc.).
- 6. No warranty card, invoice or warranty card does not match the invoice information.
- 7. The product wears out naturally.
- 8. Failure and damage caused by other non-product quality problems.

P10

1: Product Features


- High level frosted surface (fingerprint proof) + tempered glass;
- Active super Subwoofer, Dynamic, natural, powerful and surrounded with ultra-bass vibration.
- Active integration with built-in amplifier.
- Active subwoofer.
- All materials meet ROHS requirement.

2: Technical parameters


Drive Units:	10" Driver+10"passive bass vibration films;
Frequency Response:	25Hz-200Hz;
Amplifier Power Output:	1000 watts RMS short-term;
Sensitivity:	86±3dB/W/m(100Hz);
Crossover Range:	80~160Hz;
Connection Type:	5.8GWireless connection;
Signal-to-noise ratio(S/N):	>86dB(100Hz A WEIGHTED);
Features :	0.5W low standby power consumption; Thermal shutdown; Short circuit and overload protection;Permanent high frequency protection; Proprietary DSP module;
Voltage:	AC 100-120V~60Hz/AC 220-240V~50Hz;
Dimensions:	295(L)X295(W)X405(H)mm;
Net weight :	20Kg;
Gross weight:	22Kg;

3: Product Accessories


Ⓐ Power Cord * 1PC



Ⓑ RS232 Cable * 1PC



Ⓒ User Manual



P10


4: Front panel function instruction

Power Indicator LED

ON	BLUE	Detected audio input, triggered the power, in normal working mode.
STANDBY	RED	waiting for the audio signal to triggered Power, in standby mode.
OFF	Non	No power input.

Power Auto/Always on


This subwoofer can be safely left with the main power switch on continuously. The subwoofer will turn itself on automatically when an audio signal is present. If no signal is present for approximately 15 mins, the unit will switch to standby mode (indicated by red power LED color).While in standby mode, your subwoofer will draw very minimal power.



Power indicator light

P10

5: Back panel function Introduction



1: EQ MODE SWITCH

MOVIE: According to the setting of the living room, it is recommended to use in more than 20 square meters or Unconfined space.

MUSIC: Suitable for pure music, hi-fi music, listening to music in a variety of environments.

KTV: Audio effects for karaoke venues designed to provide a high quality music and singing experience.

TV: For watching TV, news programs.

2: USB SOCKET

DSP Debugging Service or power supply 5V/500mA.

3: RS232 INPUT INTERFACE

The external device sends instructions to the subwoofer, and the subwoofer switches the corresponding EQ mode.

4: VOLTAGE SELECTION SWITCH

This machine can operate in an environment of 100-120V or 220-240V. Before using the machine, please make sure the voltage switch is set to the correct position.

5: POWER INPUT SOCKET

AC100-120V~60Hz/AC220V-240V-50Hz;
Built-in fuse tube 2 PCS (T5AL/250V), size $\phi 5 \times 20 \text{mm}$

6: PAIRING INDICATOR LED


Steady on: The pairing is successful
Blinking slowly: The connection is disconnected
Quick blink: Waiting for pairing

7: PAIRING SWITCH

Press and hold this switch, and the indicator next to it will flash quickly to enter the pending pairing state.

P10


6: Finished dimension drawing



P10

7: Connect

The P10 connects to the wireless host via 5.8G wireless. First, press and hold the PAIRING button on the rear panel of the subwoofer. When the adjacent pairing indicator flashes rapidly, the unit enters pairing standby mode. Then point the remote control at the host, press and hold the  key for about 3 seconds. Release the key once PAIR appears on the host display; the host will automatically enter pairing mode. Solid indicator light on the subwoofer indicates successful pairing. Continuous rapid flashing or slow flashing means pairing failed, and re-pairing is required.



8: Setup Home Theater System


Home Theater Speaker: The two front speakers can be placed on two side of TV screen located at ¼ section of the front wall. (as shown in the picture). The speaker is tilted slightly towards the listener. It is recommended to place the rear-surround speaker in a higher position behind the listener's head. If the back wall far from the listener's seat, could consider using floor stand. If the position of center speaker is too high or too low, tilt it slightly toward the listener's ear. The center speaker should be further away from the direct line of surround speaker's front side. Using AV amplifier's automatic testing function for calibration and adjustment.

Super Subwoofer: human ear cannot distinguish the direction of the bass, the Super Sub could be placed freely. The distance of the Sub from the wall will affect the bass performance. Putting it in the corner might enhance the bass but may reduce the clarity. If you use two super Sub same time, it will enhance the performance of your home theater system.

9: Multi-channel Placement

DolbyLabs, DTS, and THX provide 5.1 and 7.1 layouts. The exact structure of these systems depends on the performance of your processor, we will also provide some experimental results for your reference.

With 5.1 and 7.1 system, the position of listener should not be too close to the rear wall. To fully perform the benefits of these systems, it is important to make sure that signals from all speakers reach DolbyLabs' multi-channel home theater system layout simultaneously.



P10

10: Subwoofer installation


Using Two Subwoofer

When using two Subwoofer, try placement near the front corners of the room, at diagonally-opposite corners of the room, or at the center points of opposing walls as shown at right.

Experimentation with subwoofer and listener placement is recommended to achieve the best results - the benefits can be substantial.

High-resolution measurements and professional system calibration are recommended for the best possible results & system performance.

Recommended subwoofer Placement Options for Two Subwoofer




Using Three or Four Subwoofer

Research indicates that the smoothest bass response for a large listening area can be achieved using four subwoofers, placing one at the midpoint of each of the four walls (although using two or three subwoofers can be almost as good).


Experimentation with subwoofer and listener placement is recommended to achieve the best results - the Benefits can be substantial.

High-resolution measurements and professional system calibration are recommended for the best possible results & system performance.


Recommended subwoofer Placement Options for Three Subwoofer



Recommended subwoofer Placement Options for Four Subwoofer



IMPORTANT SAFETY INFORMATION



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings.
- Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. Only use attachments/accessories specified by the manufacturer. Unplug the apparatus during lightning storms or when unused for long periods of time. When the product is damaged in any of the following ways, free repair service will not be provided: For example, damage caused by liquid ingress, foreign objects entering the device, exposure to rain or moisture, abnormal operation, or the product being dropped.

CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. No naked flame sources, such as lighted candles, should be placed on the apparatus.

WARNING: When the mains plug or appliance coupler is used as the disconnect device, it shall remain readily operable.



Correct disposal of this product.
This marking indicates that this product should not be disposed of with other household waste throughout the EU.
To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.
To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



This equipment is a class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

RoHS Hazardous Substances Declaration

Hazardous substance	Circuit board	Wire	Enclosure	Accessories
Pb	×	×	×	×
Hg	×	×	×	×
Cd	×	×	×	×
Cr(VI)	×	×	×	×
PBB	×	×	×	×
PBDE	×	×	×	×

Warranty Card

We are committed to providing reliable support and service throughout your product experience.

Your positive feedback is greatly appreciated and helps us continue to improve.



Authenticity Guarantee



Invoice Provided

After-Sales Service

✓7-day replacement
1.Product quality issue.
2.Damage caused during shipping.

✓12-month warranty
1.Valid within the warranty period.

!

CAUTIONS

The following conditions are not covered by the 7-day replacement service:

1. Product quality problems caused by user-caused damage.

2. Replacement requests that do not meet the policy requirements.

The following conditions are not covered by the 12-month warranty:

1.The warranty period has expired;

2.damage caused by misuse or improper handling.

Important Notes:

1.We do not accept freight collect shipments or postage-due returns.

2.Please ensure that the product is intact before returning it. If you are not satisfied with the product, please return it with all accessories and packaging.

Thank you for your understanding and cooperation.

If you have any questions, please contact us promptly.

We will assist you as soon as possible.

Website: www.snailpower.net

After-Sales Service Registration Form

Customer information

Name: _____ Telephone: _____

E-mail: _____ Postal code: _____

Address: _____

Product information

Model: _____ Product Barcode: _____

Finish/Color: _____ Serial No.: _____

Order No.: _____ Delivery No.: _____

Dealer information

Dealer Name: _____ Telephone: _____

Address: _____

Reason for Return: _____

Problem Description: _____

Others: _____

Service Request:

☐ Return

☐ Replacement



保修政策和客户服务信息

感谢您购买 SNAIL POWER 产品。如果自购买之日起12个月内出现产品质量问题，您可以享受公司的保修服务。

注意：

- 1.购买时卖方必须出具有效的购买证明。
- 2.保修卡和购买凭证由用户妥善保管，不得丢失，丢失后不得重复发放。
- 3.如果本产品出现非人为原因造成的故障，用户可使用保修卡和购买证书在保修期内到客户服务中心进行维修。

非保修情况：

在用户操作过程中，满足以下条件之一且不在保修范围内的设备。

- 1.超过保修期。
- 2.未按照用户使用说明书的要求使用而造成的损坏。
- 3.人为因素造成的损害。
- 4.未经授权的产品拆卸、维修和修改导致的故障。
- 5.不可抗力因素（如洪水、地震、雷电等）造成的损害
- 6.无保修卡、发票或保修卡与发票信息不匹配。
- 7.产品自然磨损。
- 8.其他非产品质量问题造成的故障和损坏。

P10

1：产品特性

- 表面顶级磨砂面(防指纹)+钢化玻璃;
- 主动辐射式超低音箱,丰满自然、宽松磅礴、包围感强烈的超低频振撼感;
- 有源一体式设计,内置功放;
- 有源低音炮;
- 所用的材料均符合ROHS标准;

2：技术参数

- 喇叭单元:

10" Driver+10"超低音被动单元;
- 频响范围:

25Hz-200Hz;
- 功放输出功率:

1000 watts RMS short-term;
- 灵 敏 度:

86±3dB/W/m(100Hz);
- 建议分频点:

80~160Hz;
- 输入方式:

5.8G无线输入;
- 信噪比(S/N):

>86dB(100Hz A WEIGHTED);
- 功能特性:

0.5W低待机功耗;过热关机保护;短路和过载保护;
永久高频保护;专有的DSP模块;
- 使用电源:


AC 100-120V~60Hz/AC 220-240V~50Hz;
- 成品尺寸:

295(L)X295(W)X405(H)mm
- 产品净重:

20Kg;
- 产品毛重:


22Kg;

3：标配附件



P10

4：前面板功能说明



1:电源指示灯


开机	蓝色	检测到音频信号输入，触发开机，处于正常工作状态
待机	红色	等待音频信号触发开机，处于待机状态
关闭	无	无电源输入

2:电源(自动/始终开启)

本超低音音箱可以持续安全工作，如果有音频信号输入时，超低音音箱会自动开启。如果15分钟左右都没有信号输入，超低音音箱会自动切换到待机模式（LED显红灯）。在待机模式下，您的超低音音箱会消耗最小的功率。

P10


5: 后面板功能说明



- 1: EQ模式切换
MOVIE: 按客厅使用场景设置, 建议在20平方以上或非密闭空间使用。
MUSIC: 适合纯音乐,高保真音乐, 在各种环境中倾听音乐。
KTV: 用于卡拉OK场所的音频效果, 旨在提供高质量的音乐和歌唱体验。
TV: 用于观看电视, 新闻节目。
- 2: USB插座
DSP调试服务或电源供应5V/500mA
- 3: RS232输入接口
外部设备发送指令给低音炮,低音炮进行相对应EQ模式切换。
- 4: 电压选择开关
本机可在100-120V或220-240V的环境中运行。
在使用机器之前, 请确保电压开关拨到正确位置。
- 5: 电源输入插座, AC 100-120V~60Hz/AC 220-240V~50Hz;
内置保险丝管2PCS, 规格T5AL/250V, 尺寸φ5x20mm。
- 6: 配对指示灯
常亮: 配对成功
慢闪: 断开连接
快闪: 等待配对
- 7: 配对开关
长按开关, 旁边的指示灯快闪, 进入待配对状态

P10


6: 外观尺寸图



P10

7：连接


P10与无线主机通过5.8G无线连接，首先长按超低音箱后板的PAIRING按键，旁边的配对指示灯快闪即进入待配对模式；然后遥控器对准主机，长按  键约3秒，主机显示PAIR就可以松开，自动进入配对模式。如果音箱上的指示灯常亮，表示配对成功；长时间快闪或慢闪表示配对失败，需重新配对。



8：家庭影院系统的设置

家庭影院音箱：前置主音箱可放在电视屏幕的两侧，音箱的位置约在前方的墙面1/4处（如图所示）。音箱稍微向听者位置倾斜摆放。建议将后环绕音箱放在听者头部后方的一个较高位置。如果后墙和侧墙离听者座位较远，可考虑将音箱架在落地支架上。如果中置音箱过高或过低，将其稍微向听者耳朵处倾斜。中置音箱离环绕音箱的前面板所在直线应尽可能远。调试应该使用AV功放的自动测试的功能进行校正和调整。

超重低音音箱：由于人耳无法分辨出较低沉的低音发出的方向，所以超重低音音箱可以自由摆放位置。音箱离墙壁的距离会影响低音效果。将其放在墙角会增强低音但可能会使清晰度减弱。如果同时使用两个超重低音音箱，会增强家庭影院系统的演示效果。



9：多通道系统的摆放

DolbyLabs，DTS和THX提供了5.1和7.1布局。这些系统的精确结构取决于您的处理器的性能，但我们会提供一些试验结果，以供您参考。

在5.1和7.1布局中，听者位置离后方墙壁不要太近。

为充分实现这些系统的优点，应尽量使所有音箱发出的信号同时到达听

DolbyLabs的多声道家庭影院系统摆放方案。

P10

10：低音炮音箱的安放


当使用两个低音炮

当使用两个低音炮时，试着放置在房间的前角附近，对角在房间的中心，或在相对的墙壁的中心点，如右边所示。

建议使用低音炮和听筒进行试验，以获得最佳效果——好处可以是实质性的。

为了获得最佳的结果和系统性能，建议进行高分辨率测量和专业的系统校准。

使用两个低音炮的推荐低音炮放置选择




当使用三个或者四个低音炮

研究表明，对于一个大的听区，使用四个低音炮可以达到最平稳的低音响应，将一个低音炮放置在四面墙的中心位置(尽管使用两个或三个低音炮几乎可以达到同样的效果)。


建议使用低音炮和听筒进行试验，以获得最佳效果——好处可以是实质性的。

为了获得最佳的结果和系统性能，建议进行高分辨率测量和专业的系统校准。

使用三个低音炮的推荐低音炮放置选项



使用四个低音炮的推荐低音炮放置选项



重要的安全提示



警告！
小心触电
请勿打开



为减少触电的风险，请勿私自拆开面板，机身内部无任何用户可自行更换的零部件，如果出现异常，请咨询专业人员。

 此标志表示包装盒内附带有重要的操作指引和维修说明书。

 此标志表示机身存在的高电压有可能引起触电风险。

- 请阅读此说明书。
- 请保留此说明书。
- 请留意所有的警告标示。
- 请遵循所有的操作说明。
- 请勿将本产品靠近水源。
- 仅能使用干布清洁机身。
- 请勿阻塞各通风口。
- 请按生产商的说明书进行安装操作。

- 请勿靠近任何热源进行安装，比如散热器、热调温器、火炉及其他散热设备（包括功放）。
- 请勿损坏带极性插头或接地型插头的安全性能。带极性插头一般有两个宽度不一的插片而接地型插头除这两个插片外还带一个接地插片，其中稍宽点的插片及接地插片是为了保障用户安全而提供。如果产品上的插头与用户插座不匹配，请咨询相关专业人士更换合适的插座。
- 保护好电源线，避免被踩踏或碾压，尤其是插头、便捷式插座及设备输出端口处。
- 仅使用厂商所指定的附件或零件。
- 雷电天气或长时间不使用该产品时，请将电源插头拔出。所有的维修服务，请咨询专业的维修人员。当产品出现以下任何形式的损坏时可以要求维修，比如电源线或插头损坏、液体溅入或设备内掉入异物、产品淋雨受潮、非正常操作或产品被摔落等情况。
- 警告：为减少火灾及电击的危险，请勿将产品淋雨受潮。产品不能够被溅湿，请勿将任何装有液体的容器如花瓶放在本产品上方。
- 请勿将任何明火放置于产品上面，如蜡烛。
- 警告：电源插头被作为本产品的断电装置，请保持插头能进行方便操作。



该标志表明本产品报废后应进行合理的处置且不能与生活垃圾一同处理。为了防止对环境及人体健康可能造成的危害，可对该产品进行合理回收以促进材料的可持续使用。如果要退回该产品，应通过正规的回收渠道进行回收或联系此产品的经销商，他们可对其进行无公害的安全回收。



该产品已符合II类设备的安全要求，电源连接时不需要接地。

RoHS有害物质管理

有毒&有害物质	电路板	电线	箱体	附件
铅(Pb)	×	×	×	×
汞(Hg)	×	×	×	×
镉(Cd)	×	×	×	×
六价铬(Cr(VI))	×	×	×	×
多溴联苯(PBB)	×	×	×	×
多溴联苯醚(PBDE)	×	×	×	×

保修卡

希望我们的真诚服务能够陪伴您一生。
您的反馈是我们进步的最大动力!



正品保障



提供发票

售后服务

✓7天包换

1.商品质量问题!
2.运输过程中造成损坏!

✓12个月保修

1.确定在保修时效之内!

!

注意事项

① 以下情况,不享受7天包换服务:
1.人为因素造成产品质量问题。
2.因个人主观原因提出的不符合政策要求的换货申请。

② 以下情况,不享受12个月保修服务:
1.保修期已过!
2.人为损坏或因使用不当造成的问题!

温馨提示:

1. 拒收货到付款或到付件。

2. 办理退换货前，请确保产品完好。如不满意需退换，请将产品及全部配件、包装一并退回。

首先真诚的向您道歉,无论任何原因让您需要退换货,我们都致以万分歉意!

如果您有任何问题,请及时与我们沟通,我们会尽快为您解决!

官网：www.snailpower.net

售后服务登记表

用户信息

姓 名:

联系电话:

电子邮件:

邮政编码:

家庭地址:

产品信息

机种型号:

产品条码:

表面处理:

序 列 号:

订购单号:

发货单号:

经销商信息

销售商名称:

联系电话:

地 址:

退换原因:

问题说明:

其他说明:

退换要求: ☐ 退货 ☐ 换货

